

Set up the zacktrack Puck



Connect zacktrack Puck to zacktrack WIFI

- Turn on the zacktrackPuck with the switch at the bottom.
- The LED indicates the state (green flashing → connected to network)
- The zacktrackPuck is now ready for fixture alignment

Note: If the LED indicates blue continuously → no known wifi network is found and own zacktrackPuck WIFI will be enabled. Klick the following link to [configuration_of_zacktrack_puck_wifi_network](#)

Recommended settings of zacktrack Puck

- Setup ip address: 192.168.4.1
- Recommended ip address: 172.20.1.211
- Standard Gateway: 172.20.1.1
- Subnet: 255.255.0.0

Configuration of zacktrack Puck WIFI network

If the LED shines continous blue search for a zacktrackPuck network on your device.



1. Connect your device to the network and wait for a few seconds.
2. A pop-up brings you to the zacktrackPuck config window. (You can type 192.168.4.1 in your browser to go there manually)



3. Press the  Button to scan for availabe networks.
4. Choose a network by tapping on it or entering the SSID.
Put in the password and tap save.

Note: If your desired network is not shown you can hit the scan button to rescan or enter the SSID and password manually.



1. List of all available networks (Standard WIFI → "zacktrack")
2. Credentials of chosen network

3. zactrack Puck network settings (default settings should remain unchanged)

If the configuration succeeded the following dialog comes up:



From:
<https://manual.zactrack.com/> - **zactrack**

Permanent link:
<https://manual.zactrack.com/doku.php?id=pro:zacpuck>

Last update: **2020/04/20 10:26**

