

Autofunctions App Settings

Reach this dialog via the [menu](#).



- **Zoom Sensitivity:** Determines how quickly the camera zooms in/out when using the pinch/zoom gesture in the [2D viewport](#).
- **Visualization Modes:** This setting can be used to disable certain, unneeded visualization modes entirely.
- **Load/Save Path:** This is the default file path used when [loading](#) or [saving](#) shows.

Warning: Do not change this value unless you know exactly what you are doing. This path is used by the zactrack 3 AND the autofunctions app and changing it can lead to autofunction file im-/exports not working correctly.

- **Background Alpha:** Currently unused feature.

From:

<https://manual.zactrack.com/> - zactrack

Permanent link:

https://manual.zactrack.com/doku.php?id=manual:autofunctions_menu_settings

Last update: 2022/11/09 13:01

