

Something went wrong?

In case of a failure or error Message, see follow suggestions.

Missing anchors

Check the light on the front panel.

blue : all ok

off : switched off / no power → plugin USB-C cable to charge and use the anchor

Calibration Result is bad

Check the anchor positions. Check if large equipment hides the anchor (loudspeakers, lamps,...).

Thin Materials are not a problem. See [MOUNT](#)



From:

<https://manual.zacktrack.com/> - **zacktrack**

Permanent link:

https://manual.zacktrack.com/doku.php?id=mini:measure_failure

Last update: **2022/11/09 09:41**

