

MOUNT

- Mount the 6 anchors around the stage.
- Active the Master Anchor and the other 5 Anchors with the button at the back. The color of LEDs represent different states:
 - **LED on anchor illuminates blue → anchor has power and is connected to tracking server.**
 - **LED on anchor red → anchor has power but no connection to tracking server.**
 - **LED on anchor green → anchor has power but no connection to the tracking server.**
- Connect the Master Anchor via a DMX cable with your effect devices.

Anchor Setup

All anchors should be mounted around stage on different heights. Here is an example of a simple anchor setup.



Note: Do not place an anchor directly next to a fixture



From:

<https://manual.zacktrack.com/> - zacktrack

Permanent link:

<https://manual.zacktrack.com/doku.php?id=mini:mount>

Last update: **2022/10/31 12:01**

