

BASIC PREPARATIONS

To operate a zacktrack mini System, some basic preparations are necessary.

Connect the zacktrack master anchor as seen in the lower picture (See also [Network](#)). Connect 5V USB-C Power supplies to the anchors and wait until they are fully charged (constant green light).

Put the trackers into the charging station and connect a 5V USB power supply. Wait until the trackers are fully charged (constant green light).

Hardware Setup Overview

ToDo: insert a figure adapted for MINI systems

A zacktrack Setup could look like this

ToDo: insert a figure adapted for MINI systems **Attention a zacktrack mini System is limited at 5 anchors without the master anchor!**

From:

<https://manual.zacktrack.com/> - zacktrack

Permanent link:

https://manual.zacktrack.com/doku.php?id=mini:basic_preparation

Last update: **2022/10/31 11:56**

