

MOUNT

- Mount the 8 anchors around the stage. The positions of the anchors should be as asymmetrical as possible, for good resolution in 3D 4 anchors should be up and 4 down.
- Connect the zactrack CORE (Server ETHERNET PORT1) to a network switch
- Connect the anchors with a CAT6 cable to a PoE switch within the zacNET

Note:

LED on anchor illuminates blue → anchor has power and is connected to tracking server

LED on anchor red → anchor has power but no connection to tracking server

Max. length of CAT6 with PoE is 100m. It is possible to extend the range with fiber optic cables

- Connect the zactrack CORE (Server ETHERNET PORT2) to the lighting network switch

3D Anchor Setup

All anchors should be mounted around stage on different heights. To get accurate Z-axis positions it is necessary to mount the anchors on multiple Z-levels. Below you will find 2 examples for a 3D anchor setup.

For a 3D position the system picks at least 4 anchors.

Note: You can change the tracking type from 2D to 3D direct on each tracker on the lightconsole



Note: Do not place an anchor directly next to a fixture



2D Anchor Setup

All anchors should be mounted around stage. For 2D anchor setup it is NOT necessary to mount the anchors on multiple Z-levels. Below you will find 2 examples for a 2D anchor setup.

For a 2D position the system picks at least 3 anchors.



From:

<https://manual.zactrack.com/> - **zactrack**

Permanent link:

https://manual.zactrack.com/doku.php?id=manual:mount_smart

Last update: **2022/11/08 15:32**

